




Flip Stools include Cones / Bowls as ordered (A), seat lid (B) and 4 screws and wing nuts ©




Secure Cones / Bowls using the screws and wing nuts as shown. Insert the screws from the shape / side that will be the seat top.



The screws can be hand tightened using the wing nuts. For additional security use a 3/32" hex key to tighten the screws.



For easier assembly place the parts on a soft surface horizontally or use the edge of a table to secure the screws.



Place the seat lid on the stool and enjoy!

MIOCULTURE.COM





All trademarks, service marks and trade names (MIO, product names and the MIO logo) are owned and registered by MIO. All content including but not limited to text, designs, graphics, photos and all other content ("Content") is a collective work under the United States and other copyright laws and is the proprietary property of MIO. All rights reserved. ©2025 MIOOIM LLC

Still have questions?
Drop us a line or give us a call:

Email: info@mioculture.com US Toll Free: 1 - 888 - 563 - 3916 International: +1 (215) 925 - 9359