


■■■ MIO Culture®




Glide Stools include one seat hub (A), three legs (B), one leg locking washer © and three 1/4 20 hex screws (D)




Carefully flip seat hub unto a clean and soft surface to prevent scratching. Insert legs into hub pockets until legs align with hub.



Secure legs using the leg locking washer and 1/4 20 screws. Use a hex key (not included) to secure the locking washer. Do not over tighten.



Leg shoulders should meet edge of the hub and small leg notches should be aligned to hub pocket openings as highlighted above.



Flip over the Glide Stool and Enjoy!

Still have questions? Drop us a line or give us a call:

Email: info@mioculture.com US Toll Free: 1 - 888 - 563 - 3916 International: +1 (215) 925 - 9359

MIOCULTURE.COM





All trademarks, service marks and trade names (MIO, product names and the MIO logo) are owned and registered by MIO. All content including but not limited to text, designs, graphics, photos and all other content ("Content") is a collective work under the United States and other copyright laws and is the proprietary property of MIO. All rights reserved. ©2025 MIOOIM LLC